

11200 SHORT STRAND REINFORCED FILLER

SURFACE PREPARATION:

1. Surface must be free of rust, wax, silicone, grease, dirt and other contaminants.
2. Clean metal surfaces with 13520 Wax and Grease Remover. Wipe dry while the surface is still wet.
3. Grind surface using 36 grit (or finer) disc.
4. Use clean dry air and blow surface free of dirt.
5. For maximum adhesion, apply directly to bare metal.

MIXING DIRECTIONS:

Mixing Ratio: 2% by weight. Mix 2% of cream hardener to 11200. Using a non contaminated mixing board, mix thoroughly until mixture is color consistent.

DIRECTIONS FOR USE:

1. Mix the desired quantity of product.
2. Apply mixed product using a clean spreader. Fill to desired level.
3. Allow to cure thoroughly. Wait at least 15 minutes before sanding.
4. Sand with 24-80 grit abrasive, and finish sand to desired contour.
5. If required, finish with 11310 or 11312 Flowable Blending & Finishing Putty.
6. Topcoat with a premium quality primer.
7. Clean tools with 19020 Acetone.

CAUTION: Do not return catalyzed material to can. To avoid contamination, keep cap closed after use.