


**PARTS BREAKDOWN**



**Parts List**

Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty
1	1111-01	Throttle Handle	1	15	1111-15	Rear End Plate	1	31	1111-31	Yoke	1
2	1111-02	Air Inlet Bushing	1	16	1111-16	Rotor Blade	4	32	1111-32	Reverse Button	1
6	1111-03	Exhaust Deflector	1	17	1111-17	Rotor	1	33	1111-33	1/4" Ratchet Anvil	1
4	1111-04	Muffler Felt	1	18	1111-18	Cylinder	1	34	1111-34	Spring Cap	1
5	1111-05	Throttle Valve Plug	1	20	1111-20	Front End Plate	1	35	1111-35	Spring	1
6	1111-06	O-Ring	1	21	1111-21	Ball Bearing	1	36	1111-36	Pawl	1
7	1111-07	Spring	1	22	1111-22	Internal Gear	1	37	1111-37	Needle Roller	1
8	1111-08	O-Ring	1	23	1111-23	Idler Gear	3	38	1111-38	Friction Spring	2
9	1111-09	Valve Stem	1	24	1111-24	Needle Roller	3	39	1111-39	Steel Ball	2
10	1111-10	Throttle Valve	1	25	1111-25	Crank Shaft	1	40	1111-40	1/4" Thrust Washer	1
11	1111-11	Spring Pin	1	27	1111-27	Bushing	1	41	1111-41	Washer	1
12	1111-12	Throttle Lever	1	28	1111-28	Ratchet Housing	1	42	1111-42	Internal Retaining Ring	1
13	1111-13	Ball Bearing	1	29	1111-29	Clamp Nut	1	43	1111-43	Idler Gear Plate	1
14	1111-14	Spring Pin	1	30	1111-30	Drive Bushing	1				